

**Compatibility Chart Mac OS X**

OS version	AM211/AM310/AM311	AM311S(T)	AM313X series	413/423 series	2011/3013/4013/4023 series	7013/7023 series
Mac OS 9.1 and up	yes	yes	yes	yes	no	no
Mac OS X 10.0	yes	yes	yes	yes	no	no
Mac OS X 10.1	yes	yes	yes	yes	no	no
Mac OS X 10.2	yes	yes	yes	yes	no	no
Mac OS X 10.3	yes	yes	yes	yes	no	no
Mac OS X 10.4	yes	yes	yes	yes	yes	yes
Mac OS X 10.5 (Leopard)	no	yes	yes	yes	yes	yes
Mac OS X 10.6 (Snow Leopard)	no	yes	yes*	yes	yes	yes

	DinoXcope/DinoScope
	DinoScope Only
	DinoXcope Only

\* Only on systems that COME with Snow Leopard, not for upgrades

Please note that the Microtouch functionality is currently not supported under Mac OS.

We recommend using the SW-F1 footpedal for "hands-free" picture making (only in combination with DinoXcope)